

2010 AVCOM

Emerald Coast Convention Center Fort Walton Beach, Florida July 13-14, 2010



Presented by Marty Lanning, XTREME Semiconductor





Company Information



A Texas Company founded in January 2004 Founders: Paul Hilfer and Marty Lanning Website – <u>www.xtremesemi.com</u>



12908 Trails End Road, Suite E Leander, TX 78641







Who is XTREME Semiconductor?



- A "Solutions" Company, Providing Support for Obsolete, Legacy, and End-Of-Life Semiconductor Products.
 - Manufacturer of Legacy Mil/Aero Products
 - MIL-PRF-38535 QML Q Certified
 - Custom Packaging, Source Control Drawings
 - Independent Distributor offering "Certified EOL Product"
 - Reference Standards
 - MIL-STD-883
 - IDEA-STD-1010A
 - CCAP101
 - SAE AS5553







- What is a Counterfeit Semiconductor?
- Why is there an Industry problem with Counterfeit Semiconductors and where are they coming from?





- Definition:
 - Counterfeit Semiconductor:

"The Intentional Misrepresentation or Alteration of a Product with the Intent to Defraud or Deceive the Purchaser."

- Common Examples:
 - Re-marking, Re-branding, Re-furbishing
 - Substituting Substandard or Inferior Product as Original
 - Passing One Manufactures Product Off as Another
 - Previously Used or Salvaged Product Sold as New






- Problems Facing the Industry today:
 - Ongoing Demands for Obsolete Product
 - Minimal Support for Obsolete Products from the Original OCM
 - Few "Quality" Aftermarket Suppliers
 - Industry Accepted Quality Standards and Procedures are not Implemented by many of the Brokers and Independent Distributors Servicing this Market
 - Steady Stream of Counterfeit Products Entering the Market Primarily from China





Sources of Counterfeit Components



U.S. Department of Commerce Data – Preliminary Data (as of March 4, 2009)





 So, How Do You Avoid Getting Stung by Counterfeit Components?





- Option 1: Buy from an Authorized or Franchised Distributor when Inventory Exists
 - Lowest Risk
 - Traceability (C of C) back to the OCM
- Option 2: Buy "RE-MANUFACTURED OR VALIDATED"
 product from a Trusted Aftermarket Source
 - Lower Risk Solution
 - Some offer a Product Warranty
- Option 3: Purchase from Brokerage or Non-Franchised Suppliers:
 - Highest Overall Risk and Cost
 - No Traceability (C of C) and No Product Warranty





- Broker Market Overview
 - Not All Brokers & Independent Distributors are the Same
 - Many have minimal Quality Systems and no ESD Controls
 - Some have No Experience in the Semiconductor Market
 - The Internet has Created Virtual Companies
 - Product Quality is Compromised
 - ■Traceability back to the Original OCM is unavailable
 - Limited or No Product Warranty
 - No Product Support
 - Buying Obsolete Products Requires <u>More</u> Support, Not <u>Less</u>





- What is the "<u>True Cost</u>" of Receiving a Counterfeit Product? Some of the Cost to Consider are:
 - Incoming Inspection
 - Problem Solving and Disposition
 - Administrative Efforts to Process Returns
 - Processing Multiple Purchase Orders to Replace Material
 - Lost Production Time and Revenue
 - Damage to Companies Quality Reputation





- In the Big Picture, Counterfeit Semiconductors
 Threatens Us All Levels:
 - National Security at all Levels
 - Defense and Aerospace Industry
 - National Power Grid
 - Web and World-Wide Communication Systems
 - Banks and Financial Institutions
 - USA High Tech Industries






- Industry Impact of Counterfeiting
 - Problem is Industry-Wide; Global and Growing
 - Loss of Legitimate Sales Estimated > \$100 Billion
 - Value of Counterfeit Components > \$1-10 Billion
 - 750,000 Jobs Lost
 - Most Cases are not Documented....Just Too Many
 - Electronics Retailers Association International (ERAI)
 Receives up to 200 Complaints a Month....Identified 2578
 Brokers Selling Counterfeit Components
 - If counterfeiting was stopped today, it will take years to purge the Supply Chain of these products.





- What is Lot Validation and Why is it Important?
 - Confirming the Lot Number and Lot Date Code with OCM or other Known Good Sources
 - Visually Inspect for Re-marked, Used or Re-furbished
 Material
 - Confirmation of the Die Identification (Mask ID)
 - X-Ray to Confirm Lot Consistency
 - Test to Validate the Original OCM Product Specification
- Mitigates the Risk of Buying Counterfeit Material






U.S. Department of Commerce Data - Preliminary Data (as of March 4, 2009)



M

Avoiding Counterfeit Components

Reported Counterfeit Incidents: 2005-2008



U.S. Department of Commerce - Preliminary Data (as of March 4, 2009)





- XTREME Semiconductor "Certified EOL Product"
 - Warranted to be Authentic OCM Product
 - Visual & Mark Permanency: Anomaly Inspection
 - 100% up to 100pcs, RTS Sample
 - Die ID: Die and Mask ID Verification
 - One (1) piece minimum from each lot Date Code or Lot
 - Electrical Test: 25°C Limited DC/ Limited Functional Testing
 - 100% up to 100pcs
 - X-Ray Inspection: Verifies Lot for Consistency
 - 100% up to 100pcs
 - Customized Test solutions:
 - XTREME can provide customized "Lot Validation Plans" to meet unique customer needs or specific product applications.
 - Warranty: Will Perform to Manufacturers Data Sheet
 - One (1) Year from the date of shipment.... Mirrors the Original OCM Warranty





- XTREME Semiconductor "Certified EOL Product" Process Development Considerations:
 - Must be a Cost Effective Solution
 - Assumption: Product is Valid OCM Material
 - Process Objective is to Authenticate Real OCM Material
 - Look for Anomalies that invalidate the Primary "Assumption"
 - Process to be effective in Authenticating Most IC's and Discrete Components





- Criteria for Sourcing Obsolete Product
 - Avoid Brokers/Distributors Sourcing in China
 - Utilize Brokers/Independent Distributions who are Active Members of IDEA or ERAI or ISO Certified
 - Contact Authorized Distribution: Rochester Electronics
 - Look for Stocking Distributors: Use sites such as <u>Stockingdistributors.com</u> or <u>Parthunter.com</u>
 - Do Research Prior to Buying
 - Request pictures, lot date information, lot numbers
 - Determine EOL date of product prior to purchase





- "Certified EOL Product" Inspection Results: 2008-10
 - 30-35% of all lots inspected by XTREME were rejected
 - Includes bent leads, damaged or Incorrect material
 - Eighty-five (85) lots/devices types were rejected as counterfeit or unconfirmed material.
 - 15-20% of lots presented to XTREME from Brokers are rejected <u>prior</u> to purchase. Rejection criteria:
 - Visual Anomalies
 - Lot Date Code Issues
 - Refurbished or Poor Condition






 Sanding & painting the surface of the device is a common technique used by Counterfeiters to alter the marking or misrepresent the product.














Obvious
Indication of
Remarking Using
a Process Called
"Black Topping"





M

Validation Process: Example of Re-Marking




SMD P/N does not match the manufacture's P/N (120ns vs 90ns) and the Date Code is two years past the EOL production date for this product.





Notice the Difference in the Logos? The Date Code Format? No ESD Indicators? Shiny Black Finish....











High Magnification
Shows Abrasions
from Sanding found
Under Black
Topping







This Material has been remarked and several lots of material combined into one. Notice that both products have the same lot number and product marking, but have two different packages styles.






M

Validation Process: Example of Used Material

 This type of Contamination Indicates that the Material may be Used or Pulled from a board






Validation Process: Example of Used Material

Visual indicators of material that has been used and refurbished.



PCB Solder Marks




Scratches around Mounting holes



Validation Process: Example of NEW Material

We analyze the component surface and leads to look for evidence of the device being re-surfaced or retinned.









Validation Process: Benefits to Using of X-Ray

X-Ray Can Be Used to Validate Lot Consistency and is a Non-Destructive Test










Validation Process


X-Ray can be used to identify counterfeit material in a lot of mixed material



Same product marking, two different die inside











M

Validation Process: Uses for X-Ray

Using X-Ray we were able to detect two different die types and lead frames used in the same lot of material. Upon further investigation we also identified two different die revisions.



Micron S06A Revision



Micron S12D Revision






Validation Process: Example of Die Identification

Validation of the Mask and Die ID is key to determining the authenticity of a device.








M

Validation Process: Example of Die Identification

This information is validated on every lot of XTREME "Certified EOL Product".









Certified EOL Product

- What you can expect from XTREME Semiconductor "Certified EOL Product"?
 - Original OCM Material, no Counterfeits
 - Certificate of Compliance (C of C)
 - Test Data: Die Photos, X-Ray's, Elect. Test Summary
 - Warranty: One-Year from the Date of Shipment
 - 100% Satisfaction







"Certified EOL Product"

Eliminates the Risk



Let Us Put Your Mind At Ease



